



OG Bagger HoneyComp Brake Pedal Gripper Kit Installation

1. Before you start your new kit installation, you will need to remove your stock Bagger brake pedal cover.
2. Put your new OG HoneyComp gripper on top of your stock, now naked, foot brake arm. Using a small marker, mark the 4 mounting holes where your new gripper plate covers the entire brake arm surface area. Once done, put aside your OG Brake Pedal Gripper.
3. Apply the included drill pattern sticker on top of the 4 holes mark making it as straight as possible with the brake arm edges. The tapered sticker edge should face the outside of the bike. Refer to picture below.



4. Drill all 4 passing holes using a 7/32" bit. We recommend using a center punch and smaller drill bits in the process for a better result. Apply a good amount of grease in all 4 holes to prevent corrosion.

Note. For a cleaner look you can shave down your OEM pedal arm in order for it to match your new gripper mounting surface. Just use the same drill pattern sticker as a reference. If you end up doing it, we recommend having the brake arm painted/powder coated before reinstallation.

5. Mount your new gripper plate using the supplied hardware. Lock it down tight by hand, no need for threadlocker here; we supplied locknuts
6. Enjoy!

Note: You can always go back to your stock brake pedal cover since it will hide the 4 holes drilled. No need to buy another kit when changing for a new bike. Just swap it back!